



Warming & Sterilizing Unit User Manual

Meet your Warming & Sterilizing Unit






* Do not immerse the controller in water.

Instruction

 Remove the reservoir lid, fit the cable through the reserved outlet hole. Restore the lid and warmer onto the tank. Fix the controller slot to the wall of the tank.



2. Connect the power cord to the adapter and power on.



* The unit needs an independent power supply.

Precautions

- Please read the manual carefully before use.
 Children can only operate under the parent's guide!
- 2. Do not immerse the controller in water.
- Do not look directly at or touch the UVC lamp while the unit is working.
- When cleaning the fountain or the tank, please disconnect the power supply and take the warmer out.
- After a period, scale deposits may appear on the warming bar. It is a normal.
- 6. The warmer doesn't warm up to 28°. Due to high body temperature, the warming process is not apparent. The lower the ambient temperature, the obvious the warming effect.
- UVC light can't penetrate the plastic. The visible light during UV working does not have any damage.
- After a long time of UV radiation, yellowing around the UV lamp is normal.