


Size: 120x120mm




PETONEER 湃妮

Petoneer NutriVue Feeder
User Manual
NutriVue可视宠物喂食器
使用说明书

Model / 型号: PF008


Please read this manual carefully before using.
Keep the manual in a safe place for future reference.
使用本产品前请仔细阅读本使用说明书，并妥善保管。

01 / Meet NutriVue




Lid
Desiccant Cabinet
Food Bucket
Food hopper can be lifted for cleaning.
Button
Short Press: Express Feeding
Long Press: Factory reset
Body
Micro SD Slot
Wi-Fi Indicator LED
Food Status LED
Camera
Food Outlet
Bowl
The bowl can be removed for cleaning.
Battery Compartment Cover (At the bottom)
(4 LR14 batteries can be housed as a backup battery during a power outage)
Type-C power socket (At the bottom)

Inside the box




Feeder
Bowl
Desiccant
Manual
USB Type-C to USB-A 2.0 Cable (1.2M)

02 / Operations




- Power on the feeder**
Unbox and connect the USB Type-C Cable to the power socket at the bottom of the feeder, then connect the power supply to the wall outlet.
*The power supply is not included, please buy separately!
*When the device is running on batteries, it will automatically disable Wi-Fi, switch to offline mode, and won't be controllable remotely.
- Bowl mounting**
Slide the bowl into the feeder's outlet.
- Lid removing**
Open the lid according to the marked direction, remove the desiccant from the packaging, and place it in the desiccant cabinet.
- Food filling**
Pour food into the hopper and fill it.

- Lid closing**
Lock the lid according to the marked direction.
- Manual feeding**
Short press the manual feeding button to feed instantly.
(Default quantity is one portion, customizable through the App).
- Download the Petoneer app and connect the feeder to your Wi-Fi to schedule your feeding.**
- Click Video to watch the real-time video, and tap the Feed icon to feed expressly.**




- Insert a Micro SD card.** You can choose to record continuously or by motion detection. Daily activities can be recorded to check on in the future.
*Micro SD card not included. Please buy separately.
*To consistently achieve the best experience with the Pet Cam, you should use UHS-I Micro SD cards with a Class 10 or above speed class in FAT32 format, or the recording may stop, and the unmatched storage cards may damage the footage.
In addition, the minimum storage of the TF card is 8GB, the maximum storage the Pet Cam has been tested at is 256GB.
We recommend only purchasing name-brand Micro SD cards** through official resellers.
- *Backup Battery Installation**
Use a screwdriver to open the battery compartment cover at the bottom. Put four LR14 batteries inside (note the positive and negative poles), replace the cover and tighten the screws.
Note:
You need to buy the batteries separately, and only alkaline dry batteries are supported. Before installing, make sure that there is nothing in the battery compartment. Install batteries for emergency backup in case of power failure.
If the batteries are not used for a long time, please remove them.



03 / Quick Setup

- Scan the QR code on the right and download the Petoneer app on App Store and Google Play. Click Sign up to get walked through to create your Petoneer account.
- Power on and ensure the Wi-Fi Indicator LED is flashing slowly, reflecting the device is ready to join the Wi-Fi. Open the Petoneer app and click the "+" button and get walked through the SET-UP steps.

Note:
1. The feeder doesn't support the 5GHz Wi-Fi, please make sure your Wi-Fi is 2.4G.
2. If the Wi-Fi indicator is not blinking slowly after power-on, please long press and hold the manual feed button until the indicator blinks slowly.



04 / LED Status and Specification

LED Status	Specification
Red steady on	Jam Description: NutriVue Feeder Model: PF008 Power Input: 5V 2A Capacity: 2.6L (1.2kg) Communication: Wi-Fi (2.4GHz) Range: 98.5 feet (30m) Dimension: 191*191*312mm Net Weight: 1.65kg
Red light is off	The food is more than 10%
Fast blinking red	The food is less than 10%

05 / Precautions

- Please use the device indoors and avoid exposing it to direct sunlight, as this can interfere with both the accuracy of the food level monitoring and the quality of the video image.
- Do not drop anything other than dry food into the food hopper. Otherwise, there is a risk of dysfunction or mistaken feeding.
- To prevent the feeder from being hit by pets, it is recommended to place the feeder at the corner or against the wall.
- Please shield or organize the power cord well to prevent the pet from biting the cable and causing dangerous situations such as electric shock.
- This product is only suitable for DRY FOOD, and WET FOOD is prohibited.
- It is recommended to replace the desiccant once a month, and do not fall into the hopper, and NEVER use it if it is damaged.
- The pet food's shape and density will cause some deviations from the food hopper's capacity and the feeding unit's quantity.
- After each fill-up of the hopper, there may be a deviation of two portions at the initial feeding time. It is recommended to calibrate manually (Click the manual feeding button until food is fed).
- Clean the food passage regularly to get the kibble out smoothly.
- DO NOT clean the base; please wipe it with a rag instead. After cleaning the other parts, please dry them before reinstalling them.
- Children must use it under the guidance of adults.

06 / Warranty Terms

Within the period of warranty, if the product fails with no fault of user operations, it will be repaired at Petoneer's expense. The warranty will not cover product failure in examples below:

- Intentional damage to the product by the user or third party
- Failure to operate or maintain the product following the (Q3) Quick Installation Guide Instructions.
- Failure by natural wear and tear including but not limited to scratching, corrosion, oxidation and rusting.
- Failure by non-authorized repair of the product including but not limited to user's own or third-party repairing attempts or modifications.

(All Pictures shown in the manual are for illustration purpose only. Actual product may vary due to product enhancement.)

FCC Instructions:

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Warning:
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment.
This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Environmental Conditions
Operating Temperature: 32°F to 104°F, 0°C to 40°C (indoor only)
SkyRC Technology Co., Ltd. declares that this Petoneer NutriVue Feeder (PF008), is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Directive (2014/53/EU).

Environment friendly disposal
You can help protect the environment! Please remember to respect your local regulations: dispose of nonfunctional electrical equipment with an appropriate waste disposal center.

Manufacturer: SkyRC Technology Co., Ltd.
4, 5, 8 Floors, Building 4, Metal Science Park, Guangung Road, Guanlan, Longhua District, Shenzhen, China.


Read all the instructions
When using electrical appliances, basic safety precautions should always be followed, including the following:
1. Do not touch hot surfaces. Use handles.
2. To protect against electric shock do not immerse cord, plug into water or other liquid.
3. Close supervision is necessary when any appliance is used by or near children.
4. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
5. Do not operate any appliance with a damaged cord or plug, should the appliance malfunction, or if it has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.

- The use of the accessory attachments is not recommended by the appliance manufacturer as it may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into wall outlet.
- Do not use the appliance for other than intended use.
- WARNING: Never leave the appliance unattended whilst in use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the SUPPLY CORD is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- WARNING: This tool must be placed on its stand when not in use.

SAVE THESE INSTRUCTIONS.

Manufacturer: SkyRC Technology Co., Ltd.
Address: Floors 4, 5 & 8, Building 4, Metal Technology Park, Guangung South Road, Guanlan, Longhua District, Shenzhen, China

01 / 产品概览



储粮桶盖
干燥剂盒
储粮桶 (可提出清洗)
按钮
机身
Micro SD卡槽
Wi-Fi状态指示灯
余粮状态指示灯
摄像头
出粮口
食盆 (可提出清洗)
USB Type-C 电源接口 (机身底部)
电池仓 (机身底部) (可装四节5号碱性电池, 断电时应急备用)

包装清单



喂食器
食盆
干燥剂
说明书
1.2m USB Type-C 插头电源线

02 / 使用操作




- 连接电源**
取出主机，将电源线插入主机底部，接通电源。
*设备不带电源适配器，请自行配置。
*备用电源无法取用。
- 安装食盆**
将食盆安装至出粮口下。
- 开盖**
按标识方向打开储粮桶盖，将干燥剂去除外包装后放置到干燥剂盒内。
- 加粮**
打开储粮桶盖，加入宠物干粮。
宠物干粮

- 关闭储粮桶盖**
按标识方向关闭储粮桶盖。
- 手动喂粮**
短按主机按钮，即可立即出粮。
(默认为一份，可在APP中修改份数)
- 添加设备，设置喂食计划**
下载“Petoneer APP”，添加设备，设置喂食计划
- 点击“视频”进入实时视频画面观看，并可在视频画面点击“+”快速出粮。**



- 插入Micro SD卡**，可以选择实时录像与移动侦测录像，随时查看。
*Micro SD卡需自行配置
为确保良好的拍摄效果，要求使用 UHS-I, Class 10 及以上和 FAT32 格式的 Micro SD/TF 内存卡，否则可能因为速度不足导致录制中断或文件损坏。
另外，TF卡最小容量为8GB，而Pet Cam支持最大容量为256GB Micro SD/TF内存卡。
我们建议您通过官方授权的经销商购买品牌Micro SD卡**。
- *安装备用电池**
用螺丝刀打开主机底部电池盖，将四节5号碱性电池装入电池仓（注意正负极），装回电池盖并拧紧螺丝。
提示：
备用电源需自行购买，仅支持碱性干电池。安装电池前，请确保储粮桶内无任何东西。安装电池，可供断电时应急备用。备用电池如长期不用，请取出电池取出。



03 / 快速添加设备

- 扫描右侧二维码，或前往“GooglePlay”“AppStore”下载安装“Petoneer”APP，并注册登录账号。
- 通电后，Wi-Fi指示灯闪烁，进入配置模式。请打开“Petoneer”APP，点击“+”按照提示进行设置。

提示：
(1) 喂食器不支持5GHz路由器，请使用2.4GHz路由器。
(2) 若通电开机后Wi-Fi指示灯不处于闪烁状态，请长按按钮，直至指示灯闪烁。



04 / 余粮状态指示灯与基本参数

指示灯描述	基本参数
红色熄灭	余粮约大于10%
红色快闪	余粮约小于10%
红色常亮	堵粮

基本参数
产品名称: NutriVue可视宠物喂食器
产品型号: PF008
工作电源: 5V 2A
容量: 2.6L (约1.2kg)
通信方式: Wi-Fi (2.4GHz)
通信距离: 30m
产品尺寸: 191*191*312mm
产品净重: 1.65kg
执行标准: Q/TK 002-2019
保修期: 1年

05 / 注意事项

- 请在室内环境使用，避免阳光干扰余粮监测以及视频画面画质。
- 请勿将宠物干粮以外的物品落入储粮桶。否则存在造成设备异常或造成宠物误食的风险。
- 为防止宠物扑倒，建议将喂食器放置角落或靠墙处。
- 请做好电源线绝缘或收纳，以防宠物咬电线，造成触电等危险状况。
- 此产品只适用宠物干粮，请勿放入湿粮。
- 干粮剂建议每个月更换一次，不可落入粮桶，破损勿用。
- 发粮颗粒形状及密度会对粮桶及出粮容量造成一定偏差。
- 在空粮桶中加入宠物粮后，首次出粮量可能会有两份左右偏差，建议手动校准（点击手动出粮按钮直至出粮即可）。
- 请定期清理粮道，保持出粮顺畅。
- 主机部位请勿清洗，请用抹布擦拭，其他部位清洗后，请晾干再放回喂食器主机上。
- 儿童必须在成人指导下使用。

06 / 保修条款

在保修期限内，对于正常使用Petoneer产品过程中，由于非人为导致的损坏，所产生的维修费用和人工费用，由Petoneer承担。以下情况导致的损坏不在保修条款包查中。

- 故意行为导致的损坏。
- 未按照产品使用说明书指引使用、保养该产品。
- 设备正常磨损、腐蚀、氧化、锈蚀、耗损等原因导致的损坏。
- 因在非Petoneer授权维修代理店或用户自身进行维修、改造、清洗而造成的损坏。

(为了更好的产品，我们会定期进行产品改良。产品实物可能与说明书有差异。)

服务热线: 400-808-5869

服务网址: www.petoneer.com
制造商: 天空创新科技 (深圳) 有限公司
制造地址: 深圳市龙华区观澜街道桂花社区观光路美泰工业园4栋4, 5, 8层

服务热线: 400-808-5869
服务网址: www.petoneer.com
制造商: 天空创新科技 (深圳) 有限公司
制造地址: 深圳市龙华区观澜街道桂花社区观光路美泰工业园4栋4, 5, 8层