


Size: 120x120mm




Petoneer Two-Meal Feeder User Manual

湃妮双餐喂食器 使用说明书

Model / 型号: PF003

Please read this manual carefully before using. Keep the manual in a safe place for future reference. 使用产品前请仔细阅读本使用说明书,并妥善保管


01 / Meet your Smart Feeder



Left Button: short/long press to increase/decrease the countdown time of the respective tray in 15-minute increments. Right Button: short/long press to increase/decrease the countdown time of the respective tray in 15-minute increments.

OPEN: Short press to open the left tray, then the right one. Long press for more than 5 seconds to reset the feeder to factory setting.

Inside the box



02 / Specification


Model: PF003, Power Input: 1.5V AA LR6 Battery * 4, Communication: Bluetooth, Capacity Per Compartment: 355ml (About 4.23 Oz), Suitable Pets: Cats and Small Size Dogs

Manufacturer: SkyRC Technology Co., Ltd. Address: 4,5,8/F, Building No.4, Meitai Science Park, Guangang South Road, Guihua, Guanlan, Longhua New District, Shenzhen 518110, China

03 / Operations


① Insert batteries

Unbox and insert four AA LR6 batteries into the battery compartment located on the bottom of the feeder. Use your cautions not to reverse the polarities; replace the cover and the LCD screen lights up.




② Add food and Program Feedings


Short press the OPEN button to open the left tray, and then again to open the right tray, and add food (both dry and wet food).



An ice pack can be placed at the bottom of each tray to keep it fresh. * The ice pack needs to be frozen before use!




Close the left and right lids, press the left "+" or "-" button to set the countdown time for the left meal box. Then, repeat the same step on the right tray. When the planned time is reached, the lid of the tray will pop open automatically. It is recommended to set up the feeding plan with the mobile app to save the hassle!



③ Manual Feeding

Short press the OPEN button to feed instantly!



④ App Setup

Download the Petoneer app and add devices.



04 / Quick Setup

Scan the QR code on the right and download the Petoneer App, which is available on App Store and Google Play. Click Sign up and Sign in to get walked through to connect the feeder by pressing the + icon.



05 / Icons Explained





Table with 2 columns: Icon and Description. Rows include Left Tray, Right Tray, Countdown, Bluetooth, Battery Level.

06 / Precautions

- 1. Do NOT place ice packs when serving with dry food. 2. Do NOT place anything on top of the feeder. 3. This feeder is for both dry and wet food. 4. Never rinse the feeder with water. 5. Please do not fill food beyond the edge of the tray to avoid failure. 6. When the app alerts on low power, replace the battery in time. If it is not used for a long time, please remove the battery. 7. Bulging of the ice pack after freezing is normal. 8. NEVER try to eat the ice pack. When not in use, place it in a dark place to avoid direct sunlight. 9. This feeder is suitable for cats and Small Size Dogs.

07 / Certifications

FCC Instructions: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

- Reorient or relocate the receiving antenna. - Increase the separation between the product and receiver. - Connect the product into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Environmental Conditions

Operating Temperature: 32 °F to 104 °F, (0 °C to 40 °C) (indoor only) SkyRC Technology Co., Ltd. declares that this Two-Meal Feeder(PF003), is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Directive (2014/53/EU).

Environment friendly disposal

You can help protect the environment! Please remember to respect your local regulations: dispose of nonfunctional electrical equipment with an appropriate waste disposal center.



Manufacturer: SkyRC Technology Co., Ltd. 4, 5, 8 Floor, Building 4, Meitai Science Park, Guangang Road, Guanlan, Longhua District, Shenzhen, China.

Read all the instructions

- When using electrical appliances, basic safety precautions should always be followed, including the following: 1. Do not touch hot surfaces. Use handles. 2. To protect against electric shock do not immerse cord, plug into water or other liquid. 3. Close supervision is necessary when any appliance is used by or near children. 4. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.

5. Do not operate any appliance with a damaged cord or plug, should the appliance malfunction, or if it has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.

- 6. The use of the accessory attachments is not recommended by the appliance manufacturer as it may cause injuries. 7. Do not use outdoors. 8. Do not let the cord hang over edge of table or counter, or touch hot surfaces. 9. Do not place on or near a hot gas or electric burner, or in a heated oven. 10. Always attach plug to appliance first, then plug cord into the wall outlet. 11. Do not use the appliance for other than intended use. 12. WARNING: Never leave the appliance unattended whilst in use. 13. Warning: keep the supply cord away from heating tip and metal enclosure while using. 14. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning use of the appliance by a person responsible for their safety. 15. Children should be supervised to ensure that they do not play with the appliance. 16. If the SUPPLY CORD is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. 17. WARNING: This tool must be placed on its stand when not in use. SAVE THESE INSTRUCTIONS.


08 / Warranty Terms

Within the period of warranty, if the product fails with no fault of user operations, it will be repaired at Petoneer's expense. The warranty will not cover product failure in examples below:


- 1). Intentional damage to the product by the user or third party. 2). Failure to operate or maintain the product following the (OIG) Quick Installation Guide Instructions. 3). Failure by natural wear and tear including but not limited to scratching, corrosion, oxidation and rusting. 4). Failure by non-authorized repair of the product including but not limited to user's own or third-party repairing attempts or modifications.

All Pictures shown in the manual are for illustration purpose only. Actual product may vary due to product enhancement.

01 / 产品概览



配件清单



02 / 基本参数


产品型号: PF003, 产品尺寸: 300x220x92mm, 供电方式: 四节5号电池, 产品净重: 780g, 通讯方式: 蓝牙, 产品材质: ABS, 单格容量: 355ml (约120g), 执行标准: Q/TK 002-2019, 适用对象: 猫及小型犬, 保质期: 1年

*在选择替换电池时, 请注意最大电池电压为 1.5 伏/节。

03 / 使用操作


① 装入电池

取出主机, 打开主机底部电池盖, 装入四节5号AA LR6电池(注意正负极), 盖上电池盖, 液晶屏显示。




② 开盖加粮设置喂食计划

短按“OPEN”键打开左餐盒, 再短按“OPEN”键打开右餐盒, 在餐盒里加入宠物粮食(干粮、湿粮均可)




餐盒底部可放置冰盒用于保鲜。 *冰盒需要冰冻后使用!

盖上左右餐盖, 按左边“+”或者“-”按钮设置左餐盒出粮倒计时时间, 按右边“+”或者“-”按钮设置右餐盒出粮倒计时时间。到达预计时间后, 餐盒盖会自动弹开。建议手机APP设置喂食计划, 更简单。



③ 手动喂粮

短按OPEN按钮, 即可立即出粮。



④ 添加设备, 设置喂食计划

下载“Petoneer”APP, 添加设备。



04 / 快速添加设备

扫描右侧二维码, 按照提示下载安装“Petoneer”APP, 并注册登录账号, 点击“+”按照提示进行设置。



05 / 按键和显示屏图标说明




Table with 2 columns: Icon and Description. Rows include Left Tray, Right Tray, Countdown, Bluetooth, Battery Level.

06 / 注意事项

- 1. 放干粮时请勿使用冰盒。 2. 喂食器顶部禁止放置其他杂物。 3. 本产品干粮湿粮通用。 4. 禁止用水冲洗喂食器。 5. 请不要将宠物填满超过食物盆边缘, 以免引起设备故障。 6. APP显示低电量时, 请及时更换电池。如长期不用, 请将电池取出。 7. 冰盒冷后有鼓包现象, 属正常情况。 8. 冰盒请勿食用, 不使用的状态下, 放置阴暗处, 避免阳光直射。 9. 本机适用于小型犬猫。

07 / 保修条款

在保修期限内, 对于正常使用Petoneer产品过程中, 由于非人为导致的损坏, 所产生的维修费用和人工费用, 由Petoneer承担。以下情况导致的维修不在保修条款包含中。

- (1) 故意行为导致的损坏。 (2) 未按照产品使用说明书指引使用、保养该产品。 (3) 设备正常磨损、腐蚀、氧化、锈蚀、耗损等原因导致的损失。 (4) 因非Petoneer授权维修代理店或用户自身进行维修、改造、清洗而造成的损坏。

* 为了提供更好的产品, 我们会定期进行产品改良。产品实物可能与说明书有差异。

服务热线: 400-808-5869 服务网址: www.petoneer.com

制造商: 天空创新科技(深圳)有限公司 制造地址: 深圳市龙华区观澜街道桂花社区观澜美泰工业园4栋4,5,8层